Rebooting ICCNTRL VME rack

Before doing this open a shell window and try:

- `ifd music`

If the music sounds then ICCNTRL is up and running so go back and try some other solution. If there is no music then try the solution below:

- cycle the power on ICCNTRL