Clamping motors failure during the stowing process

If during the stowing process the clamping motors should fail you will get an alarm and blinking *failure* and *MSH* or *MSA* lamps on the C2 cabinet. If this happens you will not be able to drive the motors until the alarm has been reset. To reset and continue the stowing process follow the step by step instructions below.

- let the alarm run for about fifteen seconds
- open the C2 cabinet
- there are three red buttons (*labeled H1, H2, and H3 reset*) on the top left on the inside of the cabinet. Press the *H1(H3)* to reset the alarm if the clamping motors failed to lock the Elevation (Azimuth) bolts.
- now try to lock the pin again

If this fails again, repeat the reset procedure, but this time first move the pin out so that it is no longer fully in. If even this should fail, repeat the reset procedure, first moving the pin out and nudging the telescope in either Azimuth or Elevation, before trying to put it in and lock it again.