Antenna is moving to arbitrary position

If you send the antenna to park or a source position, but the antenna starts to move rapidly to some arbitrary position, you should immediately set the brakes. Drive the antenna to its park position from the pedestal and reboot the ICCABIN and ANTLIA as described in *”How to reset ICCABIN and ANTLIA”* of the staff manual.